

for **Servicing** value, try us

level 1

£99 inc.

level 2

£184 inc.

level 3

£274 inc.

level 4

£374 inc.

Fixed Price Servicing, Levels 1-4

Fixed price servicing applicable to cars over 4 years of age and engines up to 4 cylinders† (inc diesels) - includes parts, labour and VAT (excludes Platinum Plugs).
For vehicles fitted with fully synthetic oil, a premium of £34.50 will apply.



Littlewick Green Service Station, (A4) Bath Road, Littlewick Green, Maidenhead, Berkshire SL6 3RQ
Tel: **01628 822543** Web: www.littlewick-green.co.uk

†Excluding Jaguar, Mercedes and other similar marque vehicles.

Fixed Price Servicing, Levels 1-4

CHECKLIST		LEVEL 1	LEVEL 2	LEVEL 3	LEVEL 4
1	Note any damage to exterior	◆	◆	◆	◆
2	Fit car protection kit	◆	◆	◆	◆
3	Check operation of all lights	◆	◆	◆	◆
4	Check condition of wiper blades	◆	◆	◆	◆
5	Test screen wash operation, adjust / top up	◆	◆	◆	◆
6	Check operation of air conditioning system	◆	◆	◆	◆
7	Visually inspect cooling system for leaks & test antifreeze strength	◆	◆	◆	◆
8	Inspect condition of alternator & PAS belts	◆	◆	◆	◆
9	Inspect brake fluid levels	◆	◆	◆	◆
10	Top up battery levels	◆	◆	◆	◆
11	Top up power steering fluid level	◆	◆	◆	◆
12	Fit new oil filter	◆	◆	◆	◆
13	Drain and refill oil	◆	◆	◆	◆
14	Visually inspect front brake pads	◆	◆	◆	◆
15	Visually inspect rear brake pads	◆	◆	◆	◆
16	Torque wheel nuts to correct settings	◆	◆	◆	◆
17	Inspect tyres and set tyre pressures	◆	◆	◆	◆
18	Assess brake performance & overall performance of steering and suspension on road test	◆	◆	◆	◆
19	Check for abnormal noises on the road test	◆	◆	◆	◆
20	Check operation of heating system	◆	◆	◆	◆
21	Check operation and condition of seat belts	◆	◆	◆	◆
22	Wash and leather	◆	◆	◆	◆
23	Fit new air filter	◆	◆	◆	◆
24	Provide defect report	◆	◆	◆	◆
25	Inspect brake hoses and pipes	◆	◆	◆	◆
26	Inspect suspension mountings	◆	◆	◆	◆
27	Inspect shock absorbers	◆	◆	◆	◆
28	Inspect shaft drive, joints and gaiters	◆	◆	◆	◆
29	Inspect track rod ends	◆	◆	◆	◆
30	Examine condition of exhaust and hangers	◆	◆	◆	◆
31	Refit road wheels (rotate tyres if required)	◆	◆	◆	◆
32	Assess engine performance and oil levels	◆	◆	◆	◆
33	Check clutch for free play	◆	◆	◆	◆
34	Check gear shift quality / auto gearbox operation	◆	◆	◆	◆
35	Check steering for stability, pull or wander	◆	◆	◆	◆
36	Check operation of instruments	◆	◆	◆	◆
37	Carry out diagnostic tune and reports	◆	◆	◆	◆
38	Fit new spark plugs	◆	◆	◆	◆
39	Check horn operation and tone	◆	◆	◆	◆
40	Check heated rear screen	◆	◆	◆	◆
41	Lubricate all doors, locks and hinges	◆	◆	◆	◆
42	Check electric equipment if fitted: central locking windows, sunroof and mirrors	◆	◆	◆	◆
43	Pressure test cooling system	◆	◆	◆	◆
44	Lubricate linkages and cables	◆	◆	◆	◆
45	Check power steering hoses/pumps for leaks	◆	◆	◆	◆
46	Adjust handbrake	◆	◆	◆	◆
47	Check prop shaft and universal joints	◆	◆	◆	◆
48	Inspect fuel tank for leaks	◆	◆	◆	◆
49	Inspect under body for corrosion	◆	◆	◆	◆
50	Examine steering rack for play and oil leaks	◆	◆	◆	◆
51	Inspect brake linings front and rear	◆	◆	◆	◆
52	Check wheel bearings and ball joints	◆	◆	◆	◆
53	Replace pollen filter	◆	◆	◆	◆
54	Top up gear oil level	◆	◆	◆	◆
55	Lubricate brake back plates, slide points and handbrake levers	◆	◆	◆	◆
56	Ensure caliper operation is normal	◆	◆	◆	◆
57	Top up differential level	◆	◆	◆	◆
58	Fit new fuel filter (where applicable)	◆	◆	◆	◆
59	Replace brake fluid and tappet adjustment	◆	◆	◆	◆